

COOKTOP

c o l l e c t i o n

Instructions for Use
and Warranty Details

Domino
Vitroc ceramic Hob

CH300CW
CH300CX



KLEENMAID
THE WORLD'S BEST






Congratulations on the purchase of your new Kleenmaid appliance. This appliance has been designed and manufactured to give you years of reliable performance. For best results, carefully read the instructions on how to install your new appliance. Correct installation will avoid delays and unnecessary service calls.

Once installation is complete, read this booklet and get to know the controls and the features of your new appliance.

We reserve the right to alter the specifications with no influence on the operation of the appliance. This instruction manual cannot be reason for a claim.

PRODUCT LABEL



This cooktop has been designed and constructed in accordance with the following codes and specifications:


- | | |
|-----------------|--|
| AS/NZS 3350-1 | General Requirements for Domestic electrical appliances |
| AS/NSZ 3350-2-6 | Particular Requirements for Domestic electrical cooking appliances |
| AS/NSZ 1044 | Electromagnetic Compatibility Requirements. |
-

IMPORTANT PRECAUTIONS AND RECOMMENDATIONS FOR USE OF ELECTRICAL APPLIANCES

Use of any electrical appliance implies the necessity to follow a series of fundamental rules. In particular:

- The appliance is not intended for use by young children or infirm persons without supervision
- Young children should be supervised to ensure that they do not play with the appliance

IMPORTANT PRECAUTIONS AND RECOMMENDATIONS

- When unpacking the appliance make sure that it is not damaged. If you have any doubts, do not use the appliance but consult your supplier or an engineer.
- The packing materials (plastic bags, expanded polystyrene, nails, bands etc.) must not be left within easy reach of children, because they are a possible source of danger.
- The packaging material is recyclable and is marked with the recycling symbol .
- Do not try to alter the technical properties of the appliance, because this could be dangerous.
- The manufacturer cannot be considered responsible for damage caused by improper, incorrect or irresponsible use of the appliance.
- Before disposing of any unwanted appliances it is recommended that all potentially hazardous parts be made non hazardous.
- Electrical connection must be carried out by a specialist familiar with the laws and official regulations governing such installation in your State and following the manufacturer's instructions.
- During and after use of the cooktop, certain parts will become very hot. Do not touch hot parts.
- Keep children away from the cooking hob when it is in use.
- After use, ensure that the knob is in the off position.
- Some appliances are supplied with a protective film on steel and aluminium parts. This film must be removed before using the hob.
- Do not carry out maintenance operations on the appliance without having previously disconnected it from the electric power supply.

TIPS FOR THE USER

- During and after use of the cooktop, certain parts will become very hot. Do not touch hot parts.
- Keep children away from the cooking hob when it is in use.
- Before any cleaning or maintenance, switch off the electricity to the cooktop.

INSTALLATION

TECHNICAL INFORMATION FOR THE INSTALLER

Before installing the cooktop, remove the protective film.

This cooktop can be built into a working surface 30 to 40 mm thick and 600 mm deep.

In order to install the ceramic griddle into the kitchen fixture, a hole with the dimensions shown in fig. 1 has to be made, keeping in consideration the following:

- ✓ within the fixture, between the bottom side of the ceramic griddle and the upper surface of any other appliance or internal shelf there must be a clearance of at least 30 mm;
- ✓ the ceramic hob must be kept no less than 50 mm away from any side wall;
- ✓ the rear wall must be at least 50 mm from the ceramic griddle and must withstand a temperature of 150°C.
- ✓ there must be a distance of at least 650 mm between the hob and any wall cupboard or extractor hood positioned immediately above (see fig. 2)
- ✓ the coatings of the walls of the unit or appliances near the cooktop must be heat resistant.
- ✓ Do not install the appliance near inflammable materials (eg. curtains).

Figure 1





Figure 2



FASTENING THE APPLIANCE

Each ceramic griddle is supplied with a set of tabs and screws to be fastened onto the units.

- ✓ Cut the unit (as shown in figure 1).
- ✓ Stretch gasket "D" over the edge of the hole made, being careful to overlay the junction edges.
- ✓ Turn the ceramic griddle over and put tabs "A" into the mountings, only tighten screws "B" a few turns (fig. 4).
Make sure that the tabs are mounted correctly as shown in the figures. Turn the tabs so that the cooktop can be put into the hole.

- ✓ Put the cooktop into the hole cut into the unit and position it correctly.
- ✓ Put tabs "A"; into place, tooth "C" of the tabs should go into the hole (fig. 4).
- ✓ Tighten screws "B" until the cooktop is completely secured.
- ✓ Using a sharp tool cut off the part of gasket "D" which protrudes from the cooktop.

Figure 3





Figure 4



ELECTRICAL SECTION

ELECTRICAL REQUIREMENTS

- The appliance must be connected to the mains checking that the voltage corresponds to the value given in the rating plate and that the electrical cable sections can withstand the load specified on the plate.
- The wires in the power cable are coloured in accordance with the following code:
Green/Yellow = Earth, Blue = Neutral, Brown = Active.
If the colours of the wires in the power cable to the appliance do not correspond with the coloured markings identifying the terminals in the junction terminal, proceed as follows:
 1. The wire which is coloured green and yellow must be connected to the terminal marked E (Earth) or coloured Green.
 2. The wire which is coloured blue must be connected to the terminal marked N (Neutral) or coloured Black.
 3. The wire which is coloured brown must be connected to the terminal marked L (Live) or A (Active) or coloured Red.
- The appliance must be connected directly to the mains placing a two pole switch with minimum opening between the contacts of 3 mm between the appliance and the mains.
- The power supply cable must not touch the hot parts and must be positioned so that it does not exceed 50°C above ambient.
- Once the appliance has been installed, the switch or socket must always be accessible.
- If the supply cord is damaged it must be replaced by the manufacturer or its Service Agent or a similarly qualified person in order to avoid a hazard.

N.B. The connection of the appliance to earth is mandatory.

If the installation requires alterations to the domestic electrical system call a qualified electrician.

He should also check that the socket cable section is suitable for the power drawn by the appliance.

Replacing the power cord must be done by a qualified electrician in accordance with the instructions supplied by the manufacturer and in compliance with established electrical regulations.

Before carrying out any work on the electrical section of the appliance, it must be disconnected from the mains.

REPAIRS

Replacing the supply cable

Turn the cooktop over and unhook the terminal board cover by inserting a screwdriver into the two hooks "A".

Open the cable gland by unscrewing screw "F", unscrew the terminal screws and remove the cable.

The new supply cable, of suitable type and section, is connected to the terminal board following the diagrams shown below.

SECTION OF THE SUPPLY CABLE

Use H05RR-F cables

230-240 V ~ 50/60 Hz

section: 3 x 1,5 mm²

Connection to a good earth wiring system is absolutely essential.

The manufacturer accepts no responsibility for any inconvenience caused by failure to comply with this rule.

Figure 5




Figure 6






Figure 7



ELECTRIC DIAGRAM

Figure 8




ELECTRIC DIAGRAM KEY

- F1/2 Switches
- S1 Line pilot lamp
- S2/3 Residual heat pilot lamp
- P1 Radiant heater 1700W-230V
- P2 Radiant heater 1200W-230V
- M Terminal block
- T Earth connection

VITROCERAMIC HOB

Figure 9



FEATURES

- **Electrical insulation Class I.**

GENERAL FEATURES

1. 3 circuits hotplate Ø 180 - 1700 W
2. 3 circuits hotplate Ø 145 - 1200 W

CONTROL PANEL DESCRIPTION

3. Hotplate 1 control knob
4. Hotplate 2 control knob
5. Residual heat indicator (Hotplate 1)
6. Residual heat indicator (Hotplate 2)
7. Power indicator light

How to use your Ceramic Hob

HOW TO USE THE COOKER TOP

The main characteristic of this pyroceram cooker top is that it permits rapid vertical transmission of the heat from the heating elements below to the saucepans on top.

The heat does not spread horizontally, therefore the glass stays cold only a few centimetres from the hob.

The cooking plates are shown by dark disks on the ceramic surface.

Check that the hob is clean and then switch on by turning the control knob (fig. 10).

When the top is working, the pilot light will be on.

When the hob temperature is above 60°C, the corresponding indicator light will come on to indicate that the hob is hot.

This light will stay on even after the hob has been switched off to indicate that the hob is still hot.

The residual heat persists for some time after the hob has been switched off.

During this time avoid touching the hob and take particular care if there are children nearby.

The light will go out automatically when the hob temperature drops below 60°C.

3 circuit radiant hotplate

The heating element consists of 3 electrical resistances which can operate together or separately according to the setting of the 7-position switch. It reaches the required temperature very quickly.

Figure 10





Figure 11



Position of switch	TYPE OF COOKING
0	Switched OFF
1 2	For melting operations (butter, chocolate).
2	To keep food hot and to heat small quantities of liquid (sauces, eggs).
3	To heat bigger quantities; to whip creams and sauces. (vegetables, fruits, soups).
3 4	Slow boiling, i.e.: boiled meats, spaghetti, soups, steam cooking of roasts, stews, potatoes.
4	For every kind of frying, cutlets, uncovered cooking, i.e.: risotto.
4 5	Browning of meats, roasted potatoes, fried fish, omelettes, and for boiling large quantities of water.
6	Fast frying, grilled steaks, etc.


**Do not scratch the cooktop with cutting or sharp objects.
Do not use the cooktop as a work surface.**

**Caution! The cooking hob becomes very hot during operation.
Keep children well out of reach.**

COOKING HINTS:

- To speed up the cooking time, turn the knob to maximum when you switch the cooktop on. Wait a short time and then set the knob to the required cooking position.
- Use saucepans with flat bottoms. The bottom of the saucepan should be the same diameter (or slightly larger) as the hob to ensure optimum energy consumption.
- As the hob stays hot for a considerable period of time after the cooktop has been switched off, the hob can be switched off a few minutes before the end, leaving the residual heat to complete the cooking.

Figure 12



HINTS FOR SAFE USE OF THE HOB

- Before switching on, check which knob controls the required hob. You are advised to place the saucepan on the hob before switching on and to take it off after switching off.
- Use saucepans with an even flat bottom (be careful of cast iron saucepans). Uneven bottoms can scratch the pyroceram surface. Check that the bottom is clean and dry.
- Check that the saucepan handle does not protrude from the top to avoid knocking it over. This precaution also makes it more difficult for children to reach the saucepan.
- Do not use the cooktop if the surface is broken or damaged. If you note a crack in the cooktop, switch the appliance off immediately and call the After-Sales Service.
- Do not bend over the hobs when they are on.
- Do not leave aluminium foil, grease-proof paper or plastic etc. on the hob when it is hot.
- Remember that the hobs stay hot for quite a long time (approx. 30 min.) after they have been switched off.
- Scrupulously follow the cleaning instructions.
- Do not drop heavy or sharp objects on the glass ceramic cooktop.
- Never cook the food directly on the glass ceramic cooktop, but in special pans or containers.
- Do not place saucepan lids on cooktop surface. Extreme pressure can build up while cooling and cause the cooktop to crack.

Cleaning and Maintenance

GENERAL TIPS

- **Before you begin cleaning, you must ensure that the hob is switched off.**
- It is advisable to clean when the appliance is cold, especially when cleaning the enamelled parts.
- Avoid leaving alkaline or acidic substances (lemon juice, vinegar, etc.) on the surfaces.
- Avoid using cleaning products with a chlorine or acidic base.
- Do not use a steam cleaner because the moisture can get into the appliance and make it unsafe.

ENAMELLED PARTS

- All the enamelled parts must be cleaned with a sponge and soapy water or other non-abrasive products.
- Dry preferably with a chamois leather.
If acid substances such as lemon juice, tomato conserve, vinegar etc. are left on the enamel for a long time they will etch it, making it opaque.

STAINLESS STEEL PARTS

- Clean with special products which are available on the market.
- Dry preferably with chamois leather.

CONTROL KNOB

- The control knob may be removed for cleaning but care should be taken not to damage the seal.

CLEANING THE CERAMIC HOB

Make sure that the cooktop is switched off before cleaning it.


- Remove any encrustation.
- Remove dust with a damp cloth.
- Detergents can be used, but they must not be abrasive or corrosive.
- Any remaining detergent must be completely removed with a damp cloth.
- Do not put any objects on the cooktop which can melt with heat, such as plastic objects, aluminium foil, sugar or sugar products.
- If any object melts on the cooktop, remove it immediately (while the cooktop is still hot) using a special scraper, to prevent any irreversible damage to the glass ceramic surface.
- Do not use knives or sharp objects which could damage the cooktop surface.
- Do not use abrasive sponges or pads which could irreversibly damage the glass ceramic surface.

ATTENTION: MOST IMPORTANT!

If cleaning the glass ceramic hob using a special tool (i.e. scraper) take extra care to avoid damage to seal the edges of the glass ceramic surface.

CAUTION: Any abrasive substances and non-neutral detergents are absolutely not to be used as these can cause permanent damage to these elements.

Figure 13



Descriptions and illustrations in this booklet are given as simply indicative. The manufacturer reserves the right, considering the characteristics of the models described here, at any time and without notice, to make eventual necessary modifications for their construction or for commercial needs.

Warranty and Service

DOMESTIC WARRANTY - FULL FIVE YEAR WARRANTY

In addition to all statutory rights which you, the Consumer, have under the relevant laws in respect of this appliance, during the first five years of ownership as the original purchaser of this Kleenmaid appliance, we guarantee that any fault caused by faulty material or workmanship becoming apparent will be rectified free of charge for parts and labour, provided that all service is performed during normal working hours by Kleenmaid or their designated Agents. Where the appliance is installed outside the normal servicing area of the above, the Purchaser must pay for the cost of transporting the appliance to and from the Agent or the Agent's travelling cost to and from the Purchaser's home.

COMMERCIAL WARRANTY - ONE YEAR WARRANTY

When this appliance is installed in a commercial application, you, the Consumer, have under the relevant laws in respect of this appliance, during your first one year of ownership as the original purchaser of this Kleenmaid appliance, we guarantee that any fault caused by faulty material or workmanship becoming apparent, will be rectified free of charge for parts and labour, provided that all service is performed during normal working hours by Kleenmaid or their designated Agents. Where the appliance is installed outside the normal servicing area of the above, the Purchaser must pay for the cost of transporting the appliance to and from the Agent or the Agent's travelling cost to and from the Purchaser's home.

WHAT THESE WARRANTIES DO NOT COVER

We are not responsible for any damage or malfunction unless caused by a defect in material or workmanship. This includes but is not limited to abuse, misuse, improper installation and transportation damage. We are not responsible for any consequential damages from any malfunction. The Consumer, must make the appliance available for servicing and shall bear any costs incurred for any de-installation and/or re-installation required to make the appliance available for servicing. Kleenmaid St George are not liable for any consequential damage incurred during de-installation or re-installation.

WARRANTY DOES NOT COVER REPLACEMENT OF LIGHT GLOBES OR GLASS BREAKAGE DUE TO IMPACT

In case of fractured glass do not use your appliance.

WARRANTY REGISTRATION

Please complete the enclosed warranty card and retain it together with your proof of purchase document. These documents will need to be viewed by our Service Representative should you request in warranty service.

SERVICE ASSISTANCE

To assist you when phoning our After Sales Service number to arrange a service call please complete the following details and have them ready when you call.

Model Number: Date of purchase:.....

Kleenmaid Store purchased from:..... Date of installation:.....

Other products in Kleenmaid's
range of world's best appliances:

Washers

Dryers

Vacuum Cleaners

Dishwashers

Cooktops

Rangehoods

Ovens

Refrigerators

Sinks & Taps

**For sales information on the full range of quality
kitchen and laundry appliances, phone 13 13 08**